

Configured Settings

CCD Information

Customer Name: International Flavors & Fragrances Inc.
 CCD Name: International Flavors & Fragrances Inc._2070433
 Account Number: 2070433
Model/Solution: IMC2510
 CCD Type: Hardware
 CCD Number: 12446

Manual Settings

Full Path	Value	Comments
Device Settings --> Email --> Email --> Administrator Email Address	gps-device@iff.com	
Manual Configuration --> General Configuration --> Dynamic settings --> Device Certificate	Validity Period 10 years Algorithm Signature Max key length supported by device (512/1024/2048/4096)	
Manual Configuration --> General Configuration --> Dynamic settings --> HDD enabled devices *****NOTE*****	must enable encryption and DOSS - set to overwrite method DoD for all devices configured with HDD	
Manual Configuration --> General Configuration --> Dynamic settings --> SP Modes: Copy SP Modes	SP 5-966-001 set to 1	
Network Settings --> Airprint --> AirPrint --> AirPrint	Inactive	
Network Settings --> SNMPv3 --> Protocol --> SNMP	Active	
Remote --> Remote Communications --> @Remote Registration --> Registration Options	DO NOT REGISTER: SNLX with @Remote Connector/ @Remote Connector NX	
Scanner --> Default Settings for Normal Screens (Classic) on Device --> Send File Type --> Send File Type	Multi-page: PDF	
Scanner --> Default Settings for Simplified Screens (Classic) on Device --> Send File Type --> Send File Type	Multi-page: PDF	
Security --> Network --> SSDP --> IPV4	Inactive	

Security --> Network --> WSD (Device) --> IPV4	Active
SOP --> DEVICE --> Remote Panel Operation --> Remote Panel Operation - Manual	Enabled
SP Settings --> Copy SP Modes --> SP5 - 888 --> 888 - Personal info protect	1: Protection for logs
SP Settings --> Copy SP Modes --> SP5 - 967 - 001 --> 5-967-001 – Disable Document Server	1: OFF
SP Settings --> Printer SP Modes --> SP1-001 --> 1001-006 bit 1 - Lock Sample print	1: ON
User Tools --> Administrator Tools --> General Settings --> Machine Data Encryption Settings/Encrypt	Format All Data
User Tools --> File Transfer --> General Settings --> Administrators email address	gps-device@iff.com
User Tools --> File Transfer --> SMTP --> SMTP Server Name	smtp.global.iff.com

Automatic Settings

Full Path	Value	Comments
Device Settings --> Administrator Authentication Management --> File Administrator Authentication --> File Administrator Authentication	On	
Device Settings --> Administrator Authentication Management --> File Administrator Authentication --> File Administrator Authentication --> Administrator Tools	true	
Device Settings --> Administrator Authentication Management --> Machine Administrator Authentication --> Machine Administrator Authentication	On	
Device Settings --> Administrator Authentication Management --> Machine Administrator Authentication --> Machine Administrator Authentication --> Administrator Tools	true	
Device Settings --> Administrator Authentication Management --> Machine Administrator Authentication --> Machine Administrator Authentication --> File Transfer	true	

Device Settings --> Administrator
Authentication Management --> Machine
Administrator Authentication --> Machine
Administrator Authentication --> General
Features true

Device Settings --> Administrator
Authentication Management --> Machine
Administrator Authentication --> Machine
Administrator Authentication --> Interface true

Device Settings --> Administrator
Authentication Management --> Machine
Administrator Authentication --> Machine
Administrator Authentication --> Maintenance true

Device Settings --> Administrator
Authentication Management --> Machine
Administrator Authentication --> Machine
Administrator Authentication --> Timer
Settings true

Device Settings --> Administrator
Authentication Management --> Machine
Administrator Authentication --> Machine
Administrator Authentication --> Tray Paper
Settings true

Device Settings --> Administrator
Authentication Management --> Network
Administrator Authentication --> Network
Administrator Authentication On

Device Settings --> Administrator
Authentication Management --> Network
Administrator Authentication --> Network
Administrator Authentication --> Administrator
Tools true

Device Settings --> Administrator
Authentication Management --> Network
Administrator Authentication --> Network
Administrator Authentication --> File Transfer true

Device Settings --> Administrator
Authentication Management --> Network
Administrator Authentication --> Network
Administrator Authentication --> Interface true

Device Settings --> Administrator
Authentication Management --> User
Administrator Authentication --> User
Administrator Authentication On

Device Settings --> Administrator
Authentication Management --> User
Administrator Authentication --> User
Administrator Authentication --> Administrator
Tools true

Device Settings --> Email --> Email --> Auto Specify Sender Name On

Device Settings --> Email --> Reception --> Max Reception Email Size 2

Device Settings --> Email --> SMTP --> SMTP Server Name smtp.global.iff.com

Device Settings --> Program/Change Administrator --> Administrator 1 --> Login User Name admin

Device Settings --> Program/Change Administrator --> Administrator 1 --> Login User Password 20r1c0h21

Device Settings --> Program/Change Administrator --> Administrator 2 --> Login User Name ricoh

Device Settings --> Program/Change Administrator --> Administrator 2 --> Login User Password 21!ffxx1

Device Settings --> Program/Change Administrator --> File Administrator --> Administrator 1 true

Device Settings --> Program/Change Administrator --> Machine Administrator --> Administrator 1 true

Device Settings --> Program/Change Administrator --> Network Administrator --> Administrator 1 true

Device Settings --> Program/Change Administrator --> User Administrator --> Administrator 1 true

Device Settings --> Program/Change Administrator --> User Administrator --> Administrator 2 true

Device Settings --> System --> General Settings --> Media Slot Use - Print from Memory Storage Device Prohibit

Device Settings --> System --> General Settings --> Media Slot Use - Store to Memory Device Prohibit

Network Settings --> Bonjour --> Bonjour --> IPV4 Inactive

Network Settings --> Community --> Community Name 1 --> Community name 20iFF%GpS21

Network Settings --> Community --> Community Name 1 --> IPv4	Active
Network Settings --> Community --> Community Name 2 --> Access Type	read-write
Network Settings --> Community --> Community Name 2 --> Community name	r1c0h#pCFS
Network Settings --> Community --> Community Name 2 --> IPv4	Active
Network Settings --> IPV4 --> Details --> DIPRINT Timeout Period	60
Network Settings --> IPV4 --> Details --> DNS Server	Specify
Network Settings --> IPV4 --> Details --> DNS Server --> DNS Server 1	10.13.140.12
Network Settings --> IPV4 --> Details --> DNS Server --> DNS Server 2	10.13.140.10
Network Settings --> IPV4 --> Details --> DNS Server --> DNS Server 3	0.0.0.0
Network Settings --> IPV4 --> Details --> FTP	Inactive
Network Settings --> IPV4 --> Details --> IPP	Active
Network Settings --> IPV4 --> Details --> RHPP	Active
Network Settings --> IPV4 --> Details --> RSH/RCP	Active
Network Settings --> IPV4 --> Details --> SFTP	Active
Network Settings --> IPV4 --> Details --> WSD (Device)	Active
Network Settings --> IPV4 --> Details --> WSD (Printer)	Active
Network Settings --> IPV4 --> Ethernet --> DHCP	Inactive
Network Settings --> IPV4 --> Ethernet --> Domain Name	Specify
Network Settings --> IPV4 --> Ethernet --> Domain Name --> Domain Name	global.iff.com
Network Settings --> IPV4 --> Ethernet --> Primary WINS Server	000.000.000.000
Network Settings --> IPV4 --> Ethernet --> Secondary WINS Server	000.000.000.000

Network Settings --> IPV4 --> Ethernet --> WINS	Deactive
Network Settings --> IPV6 --> IPV6 --> IPV6	Inactive
Network Settings --> SNMP --> Protocol --> IPv4	Active
Network Settings --> SNMP --> SNMP --> SNMP	Active
Network Settings --> SNMPv3 --> SNMP --> IPv4	Active
Network Settings --> SNMPv3 --> SNMPv3 Setting --> Authentication Algorithm	MD5
Network Settings --> SNMPv3 --> SNMPv3 Setting --> Encryption Algorithm	DES
Network Settings --> SNMPv3 --> SNMPv3 Setting --> Permit SNMPv3 Communication	Encryption/Cleartext
Network Settings --> SNMPv3 --> SNMPv3 Setting --> SNMPv3 Function	Active
Network Settings --> SNMPv3 --> SNMPv3 Setting --> SNMPv3 Trap Communication	Active
Printer Settings --> Printer Basic Settings --> System --> Auto Continue	On
Printer Settings --> Printer Basic Settings --> System --> Auto Continue --> Auto Continue Time	5
Printer Settings --> Printer Basic Settings --> System --> Auto Delete Store Print Jobs	On
Printer Settings --> Printer Basic Settings --> System --> Auto Delete Store Print Jobs --> Time(days)	1
Printer Settings --> Printer Basic Settings --> System --> Auto Delete Temporary Print Jobs	On
Printer Settings --> Printer Basic Settings --> System --> Auto Delete Temporary Print Jobs --> Time(days)	3
Scanner --> Send Settings --> Insert Additional Email Info --> Insert Additional Email Info	On
Scanner --> Send Settings --> Insert Additional Email Info --> Insert Additional Email Info --> Language	English
Scanner --> Send Settings --> Max Email Size --> Set max email size	On

Scanner --> Send Settings --> Max Email Size
--> Set max email size --> Max email size 35000

Security --> IEEE 802.1X --> Domain Name --> Domain Name global.iff.com

Security --> Network --> Bonjour --> IPV4 Inactive

Security --> Network --> DIPRINT --> IPV4 Active

Security --> Network --> FTP --> IPV6 Inactive

Security --> Network --> LPR --> IPV4 Active

Security --> Network --> NetBIOS over TCP/IPV4 --> IPV4 Inactive

Security --> Network --> RHPP --> IPV4 Active

Security --> Network --> RSH/RCP --> IPV4 Active

Security --> Network --> sftp --> IPV4 Inactive

Security --> Network --> SNMP --> Permit Settings by SNMPv1 and SNMPv2 On

Security --> Network --> SNMP --> SNMPv1, v2 Function Active

Security --> Network --> SNMP --> SNMPv3 Active

Security --> Network --> ssh --> IPV4 Inactive

Security --> Network --> TCP/IP --> IPV4 Active

Security --> Network --> TELNET --> IPV4 Active

Security --> Network --> WSD (Encrypted Communication of Device) --> IPV4 Active

Security --> Network --> WSD (Printer) --> IPV4 Active

Security --> Network --> WSD (Scanner) --> IPV4 Active

SOP --> PERSONAL --> Screen Device Settings --> Screen SD Card Slot Inactive

SOP --> PERSONAL --> Screen Device Settings --> Screen USB Memory Slot Inactive

User Tools --> Administrator Authentication Management --> File Administrator Authentication --> File Administrator Authentication On

User Tools --> Administrator Authentication Management --> File Administrator Authentication --> File Administrator Authentication --> Administrator Tools true

User Tools --> Administrator Authentication Management --> User Administrator Authentication --> User Administrator Authentication	On
User Tools --> Administrator Authentication Management --> User Administrator Authentication --> User Administrator Authentication --> Administrator Tools	true
User Tools --> Administrator Tools --> General Settings --> Auto erase memory setting	On
User Tools --> Administrator Tools --> General Settings --> HDD Erase Method	DoD (5220.22-M)
User Tools --> File Transfer --> General Settings --> Max reception email size	35